

Chapter 11. Hazards Identification

Hazards are everywhere. Unfortunately, a hazard is not always identified until an accident occurs. It is essential to identify the hazards and reduce the risk well in advance of an accident.

For each process in a chemical plant the following questions must be asked:

1. What are the hazards?
2. What can go wrong and how?
3. What are the chances?
4. What are the consequences?

The first question represents hazard identification. The last three questions are associated with risk assessment, considered in detail in [Chapter 12](#). Risk assessment includes a determination of the events that can produce an accident, the probability of those events, and the consequences. The consequences could include human injury or loss of life, damage to the environment, or loss of production and capital equipment. [Question 2](#) is frequently called scenario identification.

The terminology used varies considerably. Hazard identification and risk assessment are sometimes combined into a general category called hazard evaluation. Risk assessment is sometimes called hazard analysis. A risk assessment procedure that determines probabilities is frequently called probabilistic risk assessment (PRA), whereas a procedure that determines probability and consequences is called quantitative risk analysis (QRA).

[Figure 11-1](#) illustrates the normal procedure for using hazards identification and risk assessment. After a description of the process is available, the hazards are identified. The various scenarios by which an accident can occur are then determined. This is followed by a concurrent study of both the probability and the consequences of an accident. This information is assembled into a final risk assessment. If the risk is acceptable, then the study is complete and the process is operated. If the risk is unacceptable, then the system must be modified and the procedure is restarted.




Figure 11-1. Hazards identification and risk assessment procedure. Adapted from *Guidelines for Hazards Evaluation Procedures* (New York: American Institute of Chemical Engineers, 1985), pp. 1–9.

The procedure described by [Figure 11-1](#) is frequently abbreviated based on circumstances. If failure rate data on the applicable equipment are not available, then risk assessment procedures cannot be fully applied. Most plant sites (and even subunits within a plant) modify the procedure to fit their particular situation.

Hazards identification and risk assessment studies can be performed at any stage during the initial design or ongoing operation of a process. If the study is performed with the initial design, it should be done as soon as possible. This enables modifications to be easily incorporated into the final design.

Hazard identification can be performed independent of risk assessment. However, the best result is obtained if they are done together. One outcome is that hazards of low probability and minimal consequences are identified and addressed with the result that the process is “gold-plated.” This means that potentially unnecessary and expensive safety equipment and procedures are implemented. For instance, flying aircraft and tornadoes are hazards to a chemical plant. What are the chances of their occurrence, and what should be done about them? For most facilities the probability of these hazards is small: No steps are required for prevention. Likewise, hazards with reasonable probability but minimal consequences are sometimes also neglected.

An important part of the hazard identification procedure shown in [Figure 11-1](#) is the risk acceptance step. Each organization using these procedures must have suitable criteria.

Many methods are available for performing hazard identification and risk assessment.¹ Only a few of the more popular approaches are considered here. No single approach is necessarily best suited for any particular application. The selection of the best method requires experience. Most companies use these methods or adaptations to suit their particular operation.

The hazard identification methods described in this chapter include the following:

1. Process hazards checklists: This is a list of items and possible problems in the process that must be checked.
2. Hazards surveys: This can be as simple as an inventory of hazardous materials, or it can be as detailed as the Dow indexes. The Dow indexes are a formal rating system, much like an income tax form, that provides penalties for hazards and credits for safety equipment and procedures.
3. Hazards and operability (HAZOP) studies: This approach allows the mind to go free in a controlled environment. Various events are suggested for a specific piece of equipment with the participants determining whether and how the event could occur and whether the event creates any form of risk.
4. Safety review: An effective but less formal type of HAZOP study. The results are highly dependent on the experience and synergism of the group reviewing the process.

11-1. Process Hazards Checklists

A process hazards checklist is simply a list of possible problems and areas to be checked. The list reminds the reviewer or operator of the potential problem areas. A checklist can be used during the design of a process to identify design hazards, or it can be used before process operation.

A classic example is an automobile checklist that one might review before driving away on a vacation. This checklist might contain the following items:

- Check oil in engine
- Check air pressure in tires
- Check fluid level in radiator
- Check air filter
- Check fluid level in windshield washer tank
- Check headlights and taillights
- Check exhaust system for leaks
- Check fluid levels in brake system
- Check gasoline level in tank

Checklists for chemical processes can be detailed, involving hundreds or even thousands of items. But, as illustrated in the vacation example, the effort expended in developing and using checklists can yield significant results.

A typical process design safety checklist is shown in [Figure 11-2](#). Note that three checkoff columns are provided. The first column is used to indicate those areas that have been thoroughly investigated. The second column is used for those items that do not apply to the particular process. The last column is used to mark those areas requiring further investigation. Extensive notes on individual areas are kept separate from the checklist.

				Further study required ↓
				Does not apply ↓
				Completed ↓
General layout				
1. Areas properly drained?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
2. Aisleways provided?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
3. Fire walls, dikes and special guardrails needed?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
4. Hazardous underground obstructions?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
5. Hazardous overhead restrictions?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
6. Emergency accesses and exits?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
7. Enough headroom?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
8. Access for emergency vehicles?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
9. Safe storage space for raw materials and finished products?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
10. Adequate platforms for safe maintenance operations?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
11. Hoists and elevators properly designed and safeguarded?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12. Clearance for overhead power lines?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Buildings				
1. Adequate ladders, stairways and escapeways?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
2. Fire doors required?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
3. Head obstructions marked?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
4. Ventilation adequate?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
5. Need for ladder or stairway to roof?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
6. Safety glass specified where necessary?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
7. Need for fireproofed structural steel?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Process				
1. Consequences of exposure to adjacent operations considered?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
2. Special fume or dust hoods required?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
3. Unstable materials properly stored?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
4. Process laboratory checked for runaway explosive conditions?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
5. Provisions for protection from explosions?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
6. Hazardous reactions possible due to mistakes or contamination?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
7. Chemistry of processes completely understood and reviewed?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
8. Provisions for rapid disposal of reactants in an emergency?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
9. Failure of mechanical equipment possible cause of hazards?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

Further study required ↓
Does not apply ↓
Completed ↓

- 10. Hazards possible from gradual or sudden blockages in piping or equipment?
- 11. Public liability risks possible from sprays, fumes, mists or noise?
- 12. Provisions made for disposal of toxic materials?
- 13. Hazards involved in sewerage material?
- 14. Material safety data sheets available for all chemical species?
- 15. Hazards possible from simultaneous loss of two or more utilities?
- 16. Safety factors altered by design revisions?
- 17. Consequences of reasonably worst incident, or combination of incidents, reviewed?
- 18. Process diagrams correct and up-to-date?

Piping

- 1. Safety showers and eye baths required?
- 2. Sprinkler systems required?
- 3. Provisions for thermal expansion?
- 4. All overflow lines directed to safe areas?
- 5. Vent lines directed safely?
- 6. Piping specifications followed?
- 7. Washing-down hoses needed?
- 8. Check valves provided as needed?
- 9. Protection and identification of fragile pipe considered?
- 10. Possible deterioration of exterior of piping by chemicals?
- 11. Emergency valves readily accessible?
- 12. Long and large vent lines supported?
- 13. Steam condensate piping safely designed?
- 14. Relief valve piping designed to prevent plugging?
- 15. Drains to relieve pressure on suction and discharge of all process pumps?
- 16. City water lines not connected to process pipes?
- 17. Flammable fluids feeding production units shut off from a safe distance in case of fire or other emergency?
- 18. Personnel protective insulation provided?
- 19. Hot steam lines insulated?

Equipment

- 1. Designs correct for maximum operating pressure?
- 2. Corrosion allowance considered?

Further study required ↓
Does not apply ↓
Completed ↓

- 3. Special isolation for hazardous equipment?
- 4. Guards for belts, pulleys, sheaves and gears?
- 5. Schedule for checking protective devices?
- 6. Dikes for any storage tanks?
- 7. Guard rails for storage tanks?
- 8. Construction materials compatible with process chemicals?
- 9. Reclaimed and replacement equipment checked structurally and for process pressures?
- 10. Pipelines independently supported to relieve pumps and other equipment, as necessary?
- 11. Automatic lubrication of critical machinery?
- 12. Emergency standby equipment needed?

Venting

- 1. Relief valves or rupture disks required?
- 2. Materials of construction corrosion resistant?
- 3. Vents properly designed? (Size, direction, configuration?)
- 4. Flame arrestors required on vent lines?
- 5. Relief valves protected from plugging by rupture disks?
- 6. Telltale pressure gauges installed between rupture disks and relief valve?

Instrument and Electrical

- 1. All controls fail safe?
- 2. Dual indication of process variables necessary?
- 3. All equipment properly labelled?
- 4. Tubing runs protected?
- 5. Safeguards provided for process control when an instrument must be taken out of service?
- 6. Process safety affected by response lag?
- 7. Labels for all start-stop switches?
- 8. Equipment designed to permit lockout protection?
- 9. Electrical failures cause unsafe conditions?
- 10. Sufficient lighting for both outside and inside operations?
- 11. Lights provided for all sight glasses, showers and eyebaths?
- 12. Breakers adequate for circuit protection?
- 13. All equipment grounded?

	Further study required ↓	Does not apply ↓	Completed ↓
14. Special interlocks needed for safe operation?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
15. Emergency standby power on lighting equipment required?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
16. Emergency escape lighting required during power failure?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
17. All necessary communications equipment provided?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
18. Emergency disconnect switches properly marked?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
19. Special explosion proof electrical fixtures required?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety Equipment			
1. Fire extinguishers required?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2. Special respiratory equipment required?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3. Diking material required?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4. Colorimetric indicator tubes required?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5. Flammable vapor detection apparatus required?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6. Fire extinguishing materials compatible with process materials?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7. Special emergency procedures and alarms required?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Raw Materials			
1. Any materials and products require special handling equipment?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2. Any raw materials and products affected by extreme weather conditions?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3. Any products hazardous from a toxic or fire standpoint?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4. Proper containers being used?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5. Containers properly labelled for toxicity, flammability, stability, etc?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6. Consequences of bad spills considered?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7. Special instructions needed for containers or for storage and warehousing by distributors?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
8. Does warehouse have operating instructions covering each product regarded as critical?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Figure 11-2. A typical process safety checklist. A list of this type is frequently used before a more complete analysis. Adapted from Henry E. Webb, “What to Do When Disaster Strikes,” in *Safe and Efficient Plant Operation and Maintenance*, Richard Greene, ed. (New York: McGraw-Hill, 1980).

The design of the checklist depends on the intent. A checklist intended for use during the initial design of the process will be considerably different from a checklist used for a process change. Some companies have checklists for specific pieces of equipment, such as a heat exchanger or a distillation column.

Checklists should be applied only during the preliminary stages of hazard identification and should not be used as a replacement for a more complete hazard identification procedure. Checklists are most effective in identifying hazards arising from process design, plant layout, storage of chemicals, electrical systems, and so forth.

11-2. Hazards Surveys

A hazards survey can be as simple as an inventory of hazardous materials in a facility or as complicated as a rigorous procedure such as the Dow Fire and Explosion Index (F&EI)² and the Dow-Chemical Exposure Index (CEI)³, which are two popular forms of hazards survey. These are formal systematized approaches using a rating form, similar to an income tax form. The final rating number provides a relative ranking of the hazard. The F&EI also contains a mechanism for estimating the dollar loss in the event of an accident.

The Dow F&EI is designed for rating the relative hazards with the storage, handling, and processing of explosive and flammable materials. The main idea of this procedure is to provide a purely systematic approach, mostly independent of judgmental factors, for determining the relative magnitude of flammable hazards in a chemical plant. The main forms used for the computations are shown in [Figures 11-3](#) and [11-4](#).

FIRE & EXPLOSION INDEX

AREA / COUNTRY	DIVISION	LOCATION	DATE
SITE	MANUFACTURING UNIT	PROCESS UNIT	
PREPARED BY:		APPROVED BY: (Superintendent)	BUILDING
REVIEWED BY: (Management)		REVIEWED BY: (Technology Center)	REVIEWED BY: (Safety & Loss Prevention)
MATERIALS IN PROCESS UNIT			
STATE OF OPERATION		BASIC MATERIAL(S) FOR MATERIAL FACTOR	
<input type="checkbox"/> DESIGN <input type="checkbox"/> START UP <input type="checkbox"/> NORMAL OPERATION <input type="checkbox"/> SHUTDOWN			
MATERIAL FACTOR (See Table 1 or Appendices A or B) Note requirements when unit temperature over 140 °F (60 °C)			
1. General Process Hazards		Penalty Factor Range	Penalty Factor Used(1)
Base Factor		1.00	1.00
A. Exothermic Chemical Reactions		0.30 to 1.25	
B. Endothermic Processes		0.20 to 0.40	
C. Material Handling and Transfer		0.25 to 1.05	
D. Enclosed or Indoor Process Units		0.25 to 0.90	
E. Access		0.20 to 0.35	
F. Drainage and Spill Control		gal or cu.m.	0.25 to 0.50
General Process Hazards Factor (F ₁)			
2. Special Process Hazards			
Base Factor		1.00	1.00
A. Toxic Material(s)		0.20 to 0.80	
B. Sub-Atmospheric Pressure (< 500 mm Hg)		0.50	
C. Operation In or Near Flammable Range		<input type="checkbox"/> Inerted <input type="checkbox"/> Not Inerted	
1. Tank Farms Storage Flammable Liquids		0.50	
2. Process Upset or Purge Failure		0.30	
3. Always in Flammable Range		0.80	
D. Dust Explosion (See Table 3)		0.25 to 2.00	
E. Pressure (See Figure 2)		Operating Pressure _____ psig or kPa gauge Relief Setting _____ psig or kPa gauge	
F. Low Temperature		0.20 to 0.30	
G. Quantity of Flammable/Unstable Material:		Quantity _____ lb or kg H _C = _____ BTU/lb or kcal/kg	
1. Liquids or Gases in Process (See Figure 3)			
2. Liquids or Gases in Storage (See Figure 4)			
3. Combustible Solids in Storage, Dust in Process (See Figure 5)			
H. Corrosion and Erosion		0.10 to 0.75	
I. Leakage – Joints and Packing		0.10 to 1.50	
J. Use of Fired Equipment (See Figure 6)			
K. Hot Oil Heat Exchange System (See Table 5)		0.15 to 1.15	
L. Rotating Equipment		0.50	
Special Process Hazards Factor (F ₂)			
Process Unit Hazards Factor (F ₁ x F ₂) = F ₃			
Fire and Explosion Index (F ₃ x MF = F&EI)			

(1) For no penalty use 0.00.

Figure 11-3. Form used in the Dow Fire and Explosion Index. The figures and tables referenced in the form are provided in the index booklet. Source: *Dow's Fire and Explosion Index Hazard Classification Guide*, 7th ed. (1994). Reproduced by permission of the American Institute of Chemical Engineers.

LOSS CONTROL CREDIT FACTORS

1. Process Control Credit Factor (C₁)

Feature	Credit Factor Range	Credit Factor Used ⁽²⁾	Feature	Credit Factor Range	Credit Factor Used ⁽²⁾
a. Emergency Power	0.98		f. Inert Gas	0.94 to 0.96	
b. Cooling	0.97 to 0.99		g. Operating Instructions/Procedures	0.91 to 0.99	
c. Explosion Control	0.84 to 0.98		h. Reactive Chemical Review	0.91 to 0.98	
d. Emergency Shutdown	0.96 to 0.99		i. Other Process Hazard Analysis	0.91 to 0.98	
e. Computer Control	0.93 to 0.99				

C₁ Value⁽³⁾

2. Material Isolation Credit Factor (C₂)

Feature	Credit Factor Range	Credit Factor Used ⁽²⁾	Feature	Credit Factor Range	Credit Factor Used ⁽²⁾
a. Remote Control Valves	0.96 to 0.98		c. Drainage	0.91 to 0.97	
b. Dump/Blowdown	0.96 to 0.98		d. Interlock	0.98	

C₂ Value⁽³⁾

3. Fire Protection Credit Factor (C₃)

Feature	Credit Factor Range	Credit Factor Used ⁽²⁾	Feature	Credit Factor Range	Credit Factor Used ⁽²⁾
a. Leak Detection	0.94 to 0.98		f. Water Curtains	0.97 to 0.98	
b. Structural Steel	0.95 to 0.98		g. Foam	0.92 to 0.97	
c. Fire Water Supply	0.94 to 0.97		h. Hand Extinguishers/Monitors	0.93 to 0.98	
d. Special Systems	0.91		i. Cable Protection	0.94 to 0.98	
e. Sprinkler Systems	0.74 to 0.97				

C₃ Value⁽³⁾

Loss Control Credit Factor = C₁ X C₂ X C₃⁽³⁾ = (Enter on line 7 below)

PROCESS UNIT RISK ANALYSIS SUMMARY

1. Fire & Explosion Index (F&EI).....(See Front)		
2. Radius of Exposure.....(Figure 7)		ft or m
3. Area of Exposure.....		ft ² or m ²
4. Value of Area of Exposure.....		\$MM
5. Damage Factor(Figure 8)		
6. Base Maximum Probable Property Damage – (Base MPPD) [4 x 5]		\$MM
7. Loss Control Credit Factor.....(See Above)		
8. Actual Maximum Probable Property Damage – (Actual MPPD) [6 x 7]		\$MM
9. Maximum Probable Days Outage – (MPDO).....(Figure 9)	days	
10. Business Interruption – (BI)		\$MM

(2) For no credit factor enter 1.00.

(3) Product of all factors used.

Refer to *Fire & Explosion Index Hazard Classification Guide* for details.

Rev/01-94

Figure 11-4. Form used for consequences analysis. Source: *Dow's Fire and Explosion Index Hazard Classification Guide*, 7th ed. (1994). Reproduced by permission of the American Institute of Chemical Engineers.

The procedure begins with a material factor that is a function only of the type of chemical or chemicals used. This factor is adjusted for general and special process hazards. These adjustments or penalties are based on conditions such as storage above the flash or boiling point, endo- or exothermic reactions, and fired heaters. Credits for various safety systems and procedures are used for estimating the consequences of the hazard, after the fire and explosion index has been determined.

The form shown in [Figure 11-3](#) consists of three columns of numbers. The first column is the penalty column. Penalties for various unsafe situations are placed in this column. The second column contains the penalty actually used. This allows for a reduction or increase in the penalty based on extenuating circumstances not completely covered by the form. In the event of uncertainty here, the complete penalty value from the first column is used. The final column is used for computation.

The first step in the procedure is to conceptually divide the process into separate process units. A process unit is a single pump, a reactor, or a storage tank. A large process results in hundreds of individual units. It is not practical to apply the fire and explosion index to all these units. The usual approach is to select only the units that experience shows to have the highest likelihood of a hazard. A process safety checklist or hazards survey is frequently used to select the most hazardous units for further analysis.

The next step is to determine the material factor (MF) for use in the form shown in [Figure 11-3](#). [Table 11-1](#) lists MFs for a number of important compounds. This list also includes data on heat of combustion and flash and boiling point temperatures. The additional data are also used in the computation of the Dow F&EI. A procedure is provided in the complete index for computing the material factor for other compounds not listed in [Table 11-1](#) or provided in the Dow reference.

Table 11-1. Selected Data for the Dow Fire and Explosion Index^a

Compound	Material factor	Heat of combustion (Btu/lb × 10 ⁻³)	Flash point (°F)	Boiling point (°F)
Acetone	16	12.3	-4	133
Acetylene	29	20.7	Gas	-118
Benzene	16	17.3	12	176
Bromine	1	0.0	-	-
1,3-Butadiene	24	19.2	-105	24
Butane	21	19.7	Gas	31
Calcium carbide	24	9.1	-	-
Carbon monoxide	21	4.3	Gas	-313
Chlorine	1	0.0	Gas	-29
Cyclohexane	16	18.7	-4	179
Cyclohexanol	10	15.0	154	322
Diesel fuel	10	18.7	100–130	315
Ethane	21	20.4	Gas	-128
Ethylene	24	20.8	Gas	-155
Fuel oil #1	10	18.7	100–162	304–574
Fuel oil #6	10	18.7	100–270	-
Gasoline	16	18.8	-45	100–400
Hydrogen	21	51.6	Gas	-423
Methane	21	21.5	Gas	-258
Methanol	16	8.6	52	147
Mineral oil	4	17.0	380	680
Nitroglycerine	40	7.8	-	-
Octane	16	20.5	56	258
Pentane	21	19.4	<-40	97
Petroleum (crude)	16	21.3	20–90	-
Propylene	21	19.7	-162	-54
Styrene	24	17.4	88	293
Toluene	16	17.4	40	232
Vinyl chloride	24	8.0	-108	7
Xylene	16	17.6	77	279

^a Selected from *Dow's Fire and Explosion Index Hazard Classification Guide*, 7th ed. (New York: American Institute of Chemical Engineers, 1994).

In general, the higher the value of the MF, the more flammable and/or explosive the material. If mixtures of materials are used, the MF is determined from the properties of the mixture. The highest value of the MF under the complete range of operating conditions is suggested. The resulting MF value for the process is written in the space provided at the top of the form in [Figure 11-3](#).

The next step is to determine the general process hazards. Penalties are applied for the following factors:

1. Exothermic reactions that might self-heat
2. Endothermic reactions that could react because of an external heat source such as a fire
3. Material handling and transfer, including pumping and connection of transfer lines
4. Enclosed process units preventing dispersion of escaped vapors
5. Limited access for emergency equipment
6. Poor drainage of flammable materials away from the process unit

Penalties for special process hazards are determined next:

1. Toxic materials, which could impede fire fighting
2. Less than atmospheric pressure operation with a risk of outside air entering
3. Operation in or near the flammable limits
4. Dust explosion risks
5. Higher than atmospheric pressure
6. Low-temperature operation with potential embrittlement of carbon steel vessels
7. Quantity of flammable material
8. Corrosion and erosion of process unit structures
9. Leakage around joints and packings
10. Use of fired heaters, providing a ready ignition source
11. Hot oil heat exchange systems where the hot oil is above its ignition temperature
12. Large rotating equipment, including pumps and compressors

Detailed instructions and correlations for determining the general and special process hazards are provided in the complete Dow F&EI.

The general process hazard factor (F_1) and special process hazard factor (F_2) are multiplied together to produce a unit hazard factor (F_3). The Dow F&EI is computed by multiplying the unit hazard factor by the MF. [Table 11-2](#) provides the degree of hazard based on the index value.

Table 11-2. Determining the Degree of Hazard from the Dow Fire and Explosion Index

Dow Fire and Explosion Index	Degree of hazard
1–60	Light
61–96	Moderate
97–127	Intermediate
128–158	Heavy
159 and above	Severe

The Dow F&EI can be used to determine the consequences of an accident. This includes the maximum probable property damage (MPPD) and the maximum probable days outage (MPDO).

The consequences analysis is completed using the worksheet form shown in [Figure 11-4](#). The computations are completed in the Risk Analysis Summary table at the bottom of the form. The damage radius is first estimated using a correlation published in the complete Dow index. This correlation is based on the previously determined F&EI. The dollar value of the equipment within this radius is determined. Next, a damage factor (based on a correlation provided) is applied to the fraction of the equipment actually damaged by the explosion or fire. Finally, a credit factor is applied based on safety systems. The final number, in dollars, is the MPPD value. This number is used to estimate the MPDO using a correlation. Details on the procedure are available in the complete Dow reference.

The Dow indexes are useful for determining equipment spacing requirements. The F&EI uses an empirical correlation based entirely on the F&EI value to estimate the radius of exposure. It is assumed that any equipment located outside this distance would not be damaged by a fire or explosion. The CEI estimates the hazard distance for chemical exposure based on the emergency response planning guideline (ERPG) values for the particular material released.

Example 11-1.

Your plant is considering the installation of a new railcar tank unloading facility. The facility will unload nominal 25,000-gal tank cars containing either pure butadiene or cyclohexane. The unloading system will be equipped with an emergency shutdown system with remotely operated block valves. The unloading operation will be done by computer control. The railcars are inerted with nitrogen to a pressure of 40 psig, and the railcar relief system has a set pressure of 75 psig. The unloading operating instructions are written and have been reviewed by the corporate technical staff. A reactive chemicals review has already been completed on the proposed facility. Combustible gas detectors will be located at the unloading station. A deluge system will be installed at the unloading site with an excellent water supply. A diking system will surround three sides of the facility, with any spills directed to a covered impounding area.

Determine the Dow F&EI for this operation, and determine the minimum spacing from adjacent units.

Solution

The Dow Index contains most of the data required to complete the evaluation. The data for the chemical species used in this facility are

Species	Material factor	NFPA health rating	Heat of combustion (Btu/lb)	Flash point (°F)
Butadiene	24	2	19.2×10^3	-105
Cyclohexane	16	1	18.7×10^3	-4

Because the butadiene has the higher MF, it is the material we need to evaluate using the Dow F&EI.

The completed F&EI form is shown in [Figure 11-5](#). Each nonzero item on the form is discussed in what follows.

FIRE & EXPLOSION INDEX

AREA / COUNTRY North America	DIVISION North Central	LOCATION Arkansas	DATE 03/04/94
SITE No Loss	MANUFACTURING UNIT Dow Polymer	PROCESS UNIT Rail Car Unloading	
PREPARED BY: John Smith	APPROVED BY: (Superintendent) Alvin Doe	BUILDING A-103	
REVIEWED BY: (Management) Robert Big	REVIEWED BY: (Technology Center) Bill Wright	REVIEWED BY: (Safety & Loss Prevention)	
MATERIALS IN PROCESS UNIT Butadiene, Cyclohexane			
STATE OF OPERATION <input type="checkbox"/> DESIGN <input type="checkbox"/> START UP <input checked="" type="checkbox"/> NORMAL OPERATION <input type="checkbox"/> SHUTDOWN		BASIC MATERIAL(S) FOR MATERIAL FACTOR Butadiene	
MATERIAL FACTOR (See Table 1 or Appendices A or B) Note requirements when unit temperature over 140 °F (60 °C)			24
1. General Process Hazards			Penalty Factor Range
Base Factor			1.00
A. Exothermic Chemical Reactions			0.30 to 1.25
B. Endothermic Processes			0.20 to 0.40
C. Material Handling and Transfer			0.25 to 1.05
D. Enclosed or Indoor Process Units			0.25 to 0.90
E. Access			0.20 to 0.35
F. Drainage and Spill Control			gal or cu.m. 0.25 to 0.50
General Process Hazards Factor (F ₁)			1.5
2. Special Process Hazards			
Base Factor			1.00
A. Toxic Material(s) Nh=2			0.20 to 0.80
B. Sub-Atmospheric Pressure (< 500 mm Hg)			0.50
C. Operation In or Near Flammable Range <input checked="" type="checkbox"/> Inerted <input type="checkbox"/> Not Inerted			—
1. Tank Farms Storage Flammable Liquids			0.50
2. Process Upset or Purge Failure			0.30
3. Always in Flammable Range			0.80
D. Dust Explosion (See Table 3)			0.25 to 2.00
E. Pressure (See Figure 2) Operating Pressure 40 psig-or-kPa-gauge			.28
Relief Setting 75 psig-or-kPa-gauge			
F. Low Temperature			0.20 to 0.30
G. Quantity of Flammable/Unstable Material: Quantity 130K lb-or-kg			
H _C = 19.2K BTU/lb or kcal/kg			
1. Liquids or Gases in Process (See Figure 3)			—
2. Liquids or Gases in Storage (See Figure 4)			.76
3. Combustible Solids in Storage, Dust in Process (See Figure 5)			—
H. Corrosion and Erosion			0.10 to 0.75
I. Leakage – Joints and Packing			0.10 to 1.50
J. Use of Fired Equipment (See Figure 6)			—
K. Hot Oil Heat Exchange System (See Table 5)			0.15 to 1.15
L. Rotating Equipment			0.50
Special Process Hazards Factor (F ₂)			2.94
Process Unit Hazards Factor (F ₁ x F ₂) = F ₃			4.41
Fire and Explosion Index (F ₃ x MF = F&EI)			106.00

(1) For no penalty use 0.00.

FORM C-22380 Rev01-94

Figure 11-5. The Dow Fire and Explosion Index applied to the railcar unloading facility of [Example 11-1](#).

1.A. Exothermic chemical reactions: The reactive chemical review has determined that an exothermic chemical reaction here is not possible. The penalty is zero.

1.B. Endothermic chemical reactions: This penalty applies only to reactors, so the penalty is zero.

1.C. Material handling and transfer: The index documentation states: “Any loading and unloading operation involving Class I flammables or LPG-type materials where transfer lines are connected and disconnected receives a penalty of 0.50.”

1.D. Enclosed or indoor process units: The unit is outdoors, so the penalty is zero.

1.E. Access: The unit will have emergency access from all sides, so the penalty is zero.

1.F. Drainage and spill control: No penalty is applied because the dike and impounding system is present.

2.A. Toxic materials: The index suggests using a penalty value of $0.20 \times \text{NFPA Health Rating}$. Because the rating is 2, the penalty value is 0.4.

2.B. Subatmospheric pressure: The operation is pressurized, so no penalty is applied here.

2.C. Operation in or near flammable range

1. Tank farms storage flammable liquids: The tanks are inerted with a closed vapor recovery system, so the penalty here is zero.
2. Process upset or purge failure: The unit relies on inert purging to keep it out of the flammable range, so a penalty of 0.30 is applied.
3. Always in flammable range: The process is not in the flammable range during normal operation, so the penalty is zero.

2.D. Dust explosion: No dusts are involved, so the penalty is zero.

2.E. Pressure: The Dow index provides a detailed procedure for determining this penalty. The operating pressure penalty is determined from Figure 2 in the Dow index booklet using the operating pressure. In this case the operating pressure of 40 psig results in a penalty of 0.24. Second, a penalty is determined at the relief set pressure (75 psig), again using Figure 2 in the Dow index booklet. This value is 0.27. The operating pressure penalty is then divided by the set pressure penalty to get a final pressure penalty adjustment. In this case the adjustment is $0.24/0.27 = 0.8889$. This is multiplied by the operating pressure penalty to obtain $0.24(0.8889) = 0.2133$. Finally, this is multiplied by a correction factor of 1.3 because this is a liquefied flammable gas. The final penalty is $0.2133(1.3) = 0.28$.

2.F. Low temperature: Low-temperature operating is not expected, so the penalty is zero.

2.G. Quantity of flammable/unstable material

1. Liquids or gases in process: This is not part of the process, so the penalty is zero.
2. Liquids or gases in storage: The total energy contained within the storage inventory is estimated in order to determine the penalty. This requires the specific gravity of butadiene, which can be found on the MSDS sheet or other reference. This value is 0.6263. Thus the total energy is

$$(25,000 \text{ gal})(8.345 \text{ lb/gal})(0.6263) = 130,662 \text{ lb,}$$

$$(1.30 \times 10^5 \text{ lb})(19.2 \times 10^3 \text{ Btu/lb}) = 2.51 \times 10^9 \text{ Btu.}$$

From Figure 4, curve B, in the Dow index booklet, the penalty is 0.76.

3. Combustible solids in storage, dust in process: No solids are present here, so the penalty is zero.

2.H. Corrosion and erosion: Corrosion and erosion are expected to be less than 0.5 mil/yr. Thus the penalty is 0.10.

2.I. Leakage—joints and packing: The pump and gland seals are expected to have some small but minor leakage. Thus the penalty here is 0.10.

2.J. Use of fired equipment: No fired equipment is present, so the penalty is zero.

2.K. Hot oil heat exchange system: Not present, so the penalty is zero.

2.L. Rotating equipment: No large rotating equipment is present, so the penalty is zero.

These penalties and factors are summarized in [Figure 11-5](#). The resulting calculation shows an F&EI value of 106, which means that this unloading station is an intermediate hazard.

Figure 7 in the Dow index booklet provides the radius of exposure based on the F&EI value. For this case the radius is 90 ft. Thus the unloading station must be located a minimum of 90 ft from any other equipment or processes.

The Dow CEI is a simple method of rating the relative acute health hazard potential for people in neighboring plants or communities arising from possible chemical release incidents.

To use the CEI, the following items are required:

- An accurate plot plan of the plant and the surrounding area
- A simplified process flow sheet showing the containment vessels, major piping, and chemical inventories
- Physical and chemical properties of the materials investigated
- ERPG values, from [Table 5-6](#)
- The CEI guide
- The CEI form shown in [Figure 11-6](#)

CHEMICAL EXPOSURE INDEX SUMMARY

Plant _____ Location _____

Chemical _____ Total Quantity In Plant _____

Largest Single Containment _____

Pressure Of Containment _____ Temperature Of Containment _____

1. Scenario Being Evaluated _____

2. Airborne Release Rate from Scenario _____ kg/sec
_____ lb/min

3. Chemical Exposure Index _____

4.	Concentration	Hazard Distance	
	mg/m ³	PPM	meters
ERPG-1/EEPG-1	_____	_____	_____
ERPG-2/EEPG-2	_____	_____	_____
ERPG-3/EEPG-3	_____	_____	_____

5. Distances to:

	meters	feet
Public (generally considered property line)	_____	_____
Other in-company facility	_____	_____
Non-company plant or business	_____	_____

6. The CEI and the Hazard Distance establish the level of review needed.

7. If further review is required, complete Containment and Mitigation Checklist (*Chemical Exposure Index Guide*, 2nd Edition – Appendix 2, page 26) and prepare Review Package.

8. List any sights, odors or sounds that might come from your facility and cause public concern or inquiries (e.g., smoke, large relief valves, odors below hazardous levels such as mercaptans or amines, etc.)

Prepared by: _____

Reviewed by: _____

Date _____

Plant Superintendent or Manager _____

Site Review Representative _____

Additional Management Review
(if required) _____

Figure 11-6. Form used for the Dow Chemical Exposure Index. Source: Dow's *Chemical Exposure Index Guide* (New York: American Institute of Chemical Engineers, 1998). Reproduced by permission of the American Institute of Chemical Engineers.

A flowchart of the CEI procedure is shown in [Figure 11-7](#). The procedure begins with a

definition of possible release incidents. These include releases from pipes, hoses, pressure relief devices relieving directly to the atmosphere, vessels, and tank overflows and spills. The CEI guide has detailed guidelines for these incidents, as shown in [Table 4-6](#). The incidents are used with a number of simplified source models provided in the Dow guide⁴ to estimate the release rate of material. The ERPGs are then used with a simplified dispersion model to determine the CEI value and downwind hazard distances resulting from the release.




Figure 11-7. Procedure for calculating the Chemical Exposure Index (CEI). Source: Dow's Chemical Exposure Index Guide (New York: American Institute of Chemical Engineers, 1998).

Hazards surveys are suitable for identifying hazards associated with equipment design, layout, material storage, and so forth. They are not suitable for identifying hazards resulting from improper operation or upset conditions. On the other hand, this approach is fairly rigorous, requires little experience, is easy to apply, and provides a quick result.

11-3. Hazards and Operability Studies

The HAZOP study is a formal procedure to identify hazards in a chemical process facility.⁵ The procedure is effective in identifying hazards and is well accepted by the chemical industry.

The basic idea is to let the mind go free in a controlled fashion in order to consider all the possible ways that process and operational failures can occur.

Before the HAZOP study is started, detailed information on the process must be available. This includes up-to-date process flow diagrams (PFDs), process and instrumentation diagrams (P&IDs), detailed equipment specifications, materials of construction, and mass and energy balances.

The full HAZOP study requires a committee composed of a cross-section of experienced plant, laboratory, technical, and safety professionals. One individual must be a trained HAZOP leader and serves as the committee chair. This person leads the discussion and must be experienced with the HAZOP procedure and the chemical process under review. One individual must also be assigned the task of recording the results, although a number of vendors provide software to perform this function on a personal computer. The committee meets on a regular basis for a few hours each time. The meeting duration must be short enough to ensure continuing interest and input from all committee members. A large process might take several months of biweekly meetings to complete the HAZOP study. Obviously, a complete HAZOP study requires a large investment in time and effort, but the value of the result is well worth the effort.

The HAZOP procedure uses the following steps to complete an analysis:

1. Begin with a detailed flow sheet. Break the flow sheet into a number of process units. Thus the reactor area might be one unit, and the storage tank another. Select a unit for study.
2. Choose a study node (vessel, line, operating instruction).
3. Describe the design intent of the study node. For example, vessel V-1 is designed to store the benzene feedstock and provide it on demand to the reactor.
4. Pick a process parameter: flow, level, temperature, pressure, concentration, pH, viscosity, state (solid, liquid, or gas), agitation, volume, reaction, sample, component, start, stop, stability, power, inert.
5. Apply a guide word to the process parameter to suggest possible deviations. A list of guide words is shown in [Table 11-3](#). Some of the guide word process parameter combinations are meaningless, as shown in [Tables 11-4](#) and [11-5](#) for process lines and vessels.

Table 11-3. Guide Words Used for the HAZOP Procedure

Guide words	Meaning	Comments
NO, NOT, NONE	The complete negation of the intention	No part of the design intention is achieved, but nothing else happens.
MORE, HIGHER, GREATER	Quantitative increase	Applies to quantities such as flow rate and temperature and to activities such as heating and reaction.
LESS, LOWER	Quantitative decrease	Applies to quantities such as flow rate and temperature and to activities such as heating and reaction.
AS WELL AS	Qualitative increase	All the design and operating intentions are achieved along with some additional activity, such as contamination of process streams.
PART OF	Qualitative decrease	Only some of the design intentions are achieved, some are not.
REVERSE	The logical opposite of	Most applicable to activities such as flow or chemical reaction. Also applicable to substances, for example, poison instead of antidote.
OTHER THAN	Complete substitution	No part of the original intention is achieved—the original intention is replaced by something else.
SOONER THAN	Too early or in the wrong order	Applies to process steps or actions.
LATER THAN	Too late or in the wrong order	Applies to process steps or actions.
WHERE ELSE	In additional locations	Applies to process locations, or locations in operating procedures.

Table 11-4. Valid Guide Word and Process Parameter Combinations for Process Lines (x's represent valid combinations)

Process parameters	No, not, none	More, higher, greater	Less, lower	As well as	Part of	Reverse	Other than	Sooner, faster	Later, slower	Where else
Flow	x	x	x	x	x	x	x	x	x	x
Temperature		x	x					x	x	x
Pressure		x	x	x				x	x	x
Concentration	x	x	x	x	x		x	x	x	x
pH		x	x					x	x	x
Viscosity		x	x					x	x	x
State				x				x	x	x

Table 11-5. Valid Guide Word and Process Parameter Combinations for Process Vessels (x's represent valid combinations)

Process Parameters	No, not, none	More, higher, greater	Less, lower	As well as	Part of	Reverse	Other than	Sooner, faster	Later, slower	Where else
Level	x	x	x	x	x		x	x	x	x
Temperature		x	x					x	x	
Pressure		x	x	x				x	x	
Concentration	x	x	x	x	x		x	x	x	
pH		x	x					x	x	
Viscosity		x	x					x	x	
Agitation	x	x	x		x	x		x	x	
Volume	x	x	x	x	x			x	x	x
Reaction	x	x	x				x	x	x	
State				x			x	x	x	
Sample	x			x	x		x	x	x	

6. If the deviation is applicable, determine possible causes and note any protective systems.
7. Evaluate the consequences of the deviation (if any).
8. Recommend action (what? by whom? by when?).
9. Record all information.
10. Repeat steps 5 through 9 until all applicable guide words have been applied to the chosen process parameter.
11. Repeat steps 4 through 10 until all applicable process parameters have been considered for the given study node.
12. Repeat steps 2 through 11 until all study nodes have been considered for the given section and proceed to the next section on the flow sheet.

The guide words AS WELL AS, PART OF, and OTHER THAN can sometimes be conceptually difficult to apply. AS WELL AS means that something else happens in addition to the intended design intention. This could be boiling of a liquid, transfer of some additional component, or the transfer of some fluid somewhere else than expected. PART OF means that one of the components is missing or the stream is being preferentially pumped to only part of the process. OTHER THAN applies to situations in which a material is substituted for the expected material, is transferred somewhere else, or the material solidifies and cannot be transported. The guide words SOONER THAN, LATER THAN, and WHERE ELSE are applicable to batch processing.

An important part of the HAZOP procedure is the organization required to record and use the results. There are many methods to accomplish this and most companies customize their approach to fit their particular way of doing things.

[Table 11-6](#) presents one type of basic HAZOP form. The first column, denoted “Item,” is used to provide a unique identifier for each case considered. The numbering system used is a number-letter combination. Thus the designation “1A” would designate the first study node and the first guide word. The second column lists the study node considered. The third column lists the process parameter, and the fourth column lists the deviations or guide words. The next three columns are the most important results of the analysis. The

first column lists the possible causes. These causes are determined by the committee and are based on the specific deviation–guide word combination. The next column lists the possible consequences of the deviation. The last column lists the action required to prevent the hazard from resulting in an accident. Notice that the items listed in these three columns are numbered consecutively. The last several columns are used to track the work responsibility and completion of the work.

Table 11-6. HAZOP Form for Recording Data

Hazards and Operability Review

Project name:				Date:	Page of	Completed:	
Process:				No action:			
Section:				Reference drawing:		Reply date:	
Item	Study node	Process parameters	Deviations (guide words)	Possible causes	Possible consequences	Action required	Assigned to:

Example 11-2.

Consider the reactor system shown in [Figure 11-8](#). The reaction is exothermic, so a cooling system is provided to remove the excess energy of reaction. In the event that the cooling function is lost, the temperature of the reactor would increase. This would lead to an increase in reaction rate, leading to additional energy release. The result would be a runaway reaction with pressures exceeding the bursting pressure of the reactor vessel.




Figure 11-8. An exothermic reaction controlled by cooling water.

The temperature within the reactor is measured and is used to control the cooling water flow rate by a valve.

Perform a HAZOP study on this unit to improve the safety of the process. Use as study nodes the cooling coil (process parameters: flow and temperature) and the stirrer (process parameter: agitation).

Solution

The guide words are applied to the study node of the cooling coils and the stirrer with the designated process parameters.

The HAZOP results are shown in [Table 11-7](#), which is only a small part of the complete analysis.

Table 11-7. HAZOP Study Applied to the Exothermic Reactor of [Example 11-2](#).

Hazards and Operability Review

Project name: Example 11-2				Date: 1/1/93	Page 1 of 2	Completed:
Process: Reactor of Example 11-2					No action:	
Section: Reactor shown in Example 11-2			Reference drawing:		Reply date:	
Item	Study node	Process parameters	Deviations (guide words)	Possible causes	Possible consequences	Action required
1A	Cooling coils	Flow	No	1. Control valve fails closed 2. Plugged cooling coils 3. Cooling water service failure 4. Controller fails and closes valve	1. Loss of cooling, possible runaway 2. " " 3. " 4. " 5. "	1. Select valve to fail open 2. Install filter with maintenance procedure Install cooling water flow meter and low flow alarm Install high temperature alarm to alert operator 3. Check and monitor reliability of water service 4. Place controller on critical instrumentation list 5. See 1A.1 1. Instruct operators and update procedures
1B			High	5. Air pressure fails, closing valve 1. Control valve fails open	1. Reactor cools, reactant conc. builds, possible runaway on heating	DAC 1/93
1C			Low	2. Controller fails and opens valve 1. Partially plugged cooling line 2. Partial water source failure 3. Control valve fails to respond	2. " 1. Diminished cooling, possible runaway 2. " 3. "	DAC 1/93
1D 1E 1F			As well as, part of, reverse	1. Contamination of water supply 1. Covered under 1C 1. Failure of water source resulting in backflow 2. Backflow due to high backpressure	1. Not possible here 1. Loss of cooling, possible runaway 2. "	JFL 1/93
1G 1H 1I			Other than, sooner than, later than	1. Not considered possible 1. Cooling normally started early 1. Operator error	1. None 1. Temperature rises, possible runaway	X X
1J 1K 1L		Temp.	Where else Low High	1. Not considered possible 1. Low water supply temperature 1. High water supply temperature	1. Interlock between cooling flow and reactor feed 1. None 1. Install high flow alarm and/or cooling water high temp. alarm	JW 1/93
2A	Stirrer	Agitation	No	1. Stirrer motor malfunction 2. Power failure	1. Cooling system capacity limited, temp. increases 1. No mixing, possible accumulation of unreacted materials 2. Monomer feed continues, possible accumulation of unreacted materials 1. None	JW 1/93 JW 1/93 JW 2/93
2B			More	1. Stirrer motor controller fails, resulting in high motor speed	2. Monomer feed valve must fail closed on power loss	X

The potential process modifications resulting from this study ([Example 11-2](#)) are the following:

- Install a high-temperature alarm to alert the operator in the event of cooling function loss
- Install a high-temperature shutdown system (this system would automatically shut down the process in the event of a high reactor temperature; the shutdown temperature would be higher than the alarm temperature to provide the operator with the opportunity to restore cooling before the reactor is shut down)
- Install a check valve in the cooling line to prevent reverse flow (a check valve could be installed both before and after the reactor to prevent the reactor contents from flowing upstream and to prevent the backflow in the event of a leak in the coils)
- Periodically inspect the cooling coil to ensure its integrity
- Study the cooling water source to consider possible contamination and interruption of supply

- Install a cooling water flow meter and low-flow alarm (which will provide an immediate indication of cooling loss)

In the event that the cooling water system fails (regardless of the source of the failure), the high-temperature alarm and emergency shutdown system prevents a runaway reaction. The review committee performing the HAZOP study decided that the installation of a backup controller and control valve was not essential. The high-temperature alarm and shutdown system prevents a runaway reaction in this event. Similarly, a loss of coolant water source or a plugged cooling line would be detected by either the alarm or the emergency shutdown system. The review committee suggested that all coolant water failures be properly reported and that if a particular cause occurred repeatedly, then additional process modifications were warranted.

[Example 11-2](#) demonstrates that the number of suggested process changes is great, although only a single process intention is considered.

The advantage to this approach is that it provides a more complete identification of the hazards, including information on how hazards can develop as a result of operating procedures and operational upsets in the process. Companies that perform detailed HAZOPs studies find that their processes operate better and have less downtime, that their product quality is improved, that less waste is produced, and that their employees are more confident in the safety of the process. The disadvantages are that the HAZOP approach is tedious to apply, requires considerable staff time, and can potentially identify hazards independent of the risk.

11-4. Safety Reviews

Another method that is commonly used to identify safety problems in laboratory and process areas and to develop solutions is the safety review. A “safety review” brings together a diverse group of people to review a project or operation with a broad safety perspective. The review team identifies and eliminates hazards in the design and procedures. The review process includes finding initiating events or upset conditions that can cause an accident. The team subsequently develops recommendations including new, modified, and improved equipment, controls, and procedures (operating, emergency, maintenance, etc.). The focus should be on developing a high-quality review that prevents personnel injuries, equipment damage or failures, and business interruptions.

Safety reviews include a review of previous accidents and incidents in similar plants or processes. Some incidents are referred to as “near-misses,” meaning that a serious consequence did not occur but could have. Incident investigations or case histories contain actions to prevent a recurrence of similar incidents.⁶ They identify the underlying causes of incidents and outline steps to be implemented to prevent similar events. The study of previous accident and incident reports helps the reviewers avoid repeating past mistakes; that is, learn from history or you’re doomed to repeat it.

The review should be conducted periodically during the entire life of a project. The first review (before the detailed design) is the most important, because changes in the original design are less expensive compared to changes in an operating plant. Often an informal safety review will identify the need for a more detailed review, such as a formal safety

review described in [Section 11-3](#), or other PHA methods described in [Section 11-5](#).^{7,8} After startup, the periodic reviews should be conducted about every year or whenever the process adds new equipment, new chemicals, new reactions, and new procedures.

A safety review is a cooperative, constructive, and creative process that improves the safety and performance of the process. Safety reviews are positive experiences, and good reviews prevent the dreadful experiences associated with accidents and accident investigations. An especially high-quality review is not limited to environmental and safety consequences but is expanded to include operability and product quality concerns.⁹

In all of the methods mentioned above, checklists are recommended to facilitate the review process. A typical checklist is shown in [Figure 11-2](#). The reviewers should develop checklists specifically tailored to the plant and personnel conducting the review. An adaptation of [Figure 11-2](#) is shown in [Table 11-8](#).

Table 11-8. Checklist for Informal and Formal Safety Reviews

Design: Design features to prevent accidents	<p>Materials:</p> <ol style="list-style-type: none"> Flammability—AIT, LFL/UFL, flash point Explosivity—conditions to prevent Toxicity—TLV-TWA, IDLH, required protection Corrosivity and compatibility—correct materials of construction Waste disposal—equipment, personnel, and legal constraints Storage—constraints including stability in storage Static electricity—bonding and grounding Reactivity—reactivity alone or with other components in the process, effect of impurities, temperatures for auto-reactions <p>Equipment:</p> <ol style="list-style-type: none"> Safety margins—temperature, pressure, flow, level, etc. Pressure relief—scenarios, worst cases, correct type and size Plant arrangement—spacing adequate, flame arrestors, remotely operated safety control valves, containment of chemicals Electrical equipment—electrical classifications Controls—redundancy and fail-safe designs <p>Procedures: Operating and maintenance procedures for construction, startup, operation, cleaning, and shutdown, including emergency situations and normal operation</p>
Construction: Construction practices to prevent accidents in specific area and adjacent areas	<p>Materials: Authorized individuals check materials received in relationship to specifications, spare parts</p> <p>Equipment: Hydrostatic tests, mechanical integrity of equipment and controls</p> <p>Procedures: Craftsmen trained, permits used appropriately, house-keeping, maintenance defined and scheduled</p>
Startups: Thought and actions that are dedicated to this critical and hectic period to prevent problems	<p>Materials: All raw materials in place, and disposal methods for off-specification materials</p> <p>Equipment:</p> <ol style="list-style-type: none"> Actual equipment, pipes and controls as specified in the design documents (after including the recommendations of the safety review) Equipment purged, blinds removed, instrument and interlock checks completed <p>Procedures: Procedures and training completed, detailed plans communicated</p>
Operation: Procedures to help plant personnel to remain diligent to minimize operating hazards	<p>Conduct periodic audits to be sure materials, equipment, procedures, training (operators and maintenance), and permit systems are appropriate and current</p>
Cleaning: Procedures for routine and emergency situations	<p>Procedures must be in place for cleaning equipment, and for disposing of cleaning materials</p>
Shutdown: Procedures for systematic and safe shutdowns	<p>Procedures for handling all chemicals, cleaning equipment, disposing of chemicals and materials, inerting equipment and pipe systems, and a system to keep the system in a safe shutdown mode, and a procedure in place for the transition from shutdown to startup</p>

The first review uses a checklist for each of the six phases of a project's life (see [Table 11-](#)

[8](#), that is, design construction, startup, operation, cleaning, and shutdown.⁷ The periodic and follow-up reviews include the last four items: startup, operation, cleaning, and shutdown.

There are two types of safety reviews: the informal and the formal.

Informal Review

The *informal safety review* is used for small changes to existing processes and for small bench-scale or laboratory processes. The informal safety review procedure usually involves just two or three people. It includes the individual responsible for the process and one or two others not directly associated with the process but experienced with proper safety procedures. The idea is to provide a lively dialogue where ideas can be exchanged and safety improvements can be developed.

The reviewers simply meet in an informal fashion to examine the process equipment and operating procedures and to offer suggestions on how the safety of the process might be improved. Significant improvements should be summarized in a memo for others to reference in the future. The improvements must be implemented before the process is operated.

Example 11-3.

Consider the laboratory reactor system shown in [Figure 11-9](#). This system is designed to react phosgene (COCl_2) with aniline to produce isocyanate and HCl. The reaction is shown in [Figure 11-10](#). The isocyanate is used for the production of foams and plastics.




Figure 11-9. Original design of phosgene reactor before informal safety review.




Figure 11-10. Reaction stoichiometry for phosgene reactor.

Phosgene is a colorless vapor with a boiling point of 46.8°F . Thus it is normally stored as a liquid in a container under pressure above its normal boiling point temperature. The TLV for phosgene is 0.1 ppm, and its odor threshold is 0.5–1 ppm, well above the TLV.

Aniline is a liquid with a boiling point of 364°F . Its TLV is 2 ppm. It is absorbed through the skin.

In the process shown in [Figure 11-9](#) the phosgene is fed from the container through a valve into a fritted glass bubbler in the reactor. The reflux condenser condenses aniline vapors and returns them to the reactor. A caustic scrubber is used to remove the phosgene and HCl vapors from the exit vent stream. The complete process is contained in a hood.

Conduct an informal safety review of this process.

Solution

The safety review was completed by two individuals. The final process design is shown in [Figure 11-11](#). The changes and additions to the process are as follows:

1. Vacuum is added to reduce boiling temperature
2. Relief system is added with an outlet to a scrubber to prevent hazards resulting from a plugged fritted glass bubbler
3. Flow indicator provides visual indication of flow
4. Bubblers are used instead of scrubbers because they are more effective
5. Ammonium hydroxide bubbler is more effective for absorbing phosgene
6. Trap catches liquid phosgene
7. Pail of caustic is added (the phosgene cylinder would be dumped into this pail in the event of a cylinder or valve leak; the caustic would absorb the phosgene)




Figure 11-11. Final design of phosgene reactor after informal safety review.

In addition, the reviewers recommended the following: (1) Hang phosgene indicator paper around the hood, room, and operating areas (this paper is normally white but turns brown when exposed to 0.1 ppm of phosgene), (2) use a safety checklist, daily, before the process is started, and (3) post an up-to-date process sketch near the process.

Formal Review

The *formal safety review* is used for new processes, substantial changes in existing processes, and processes that need an updated review. The formal safety review is a three-step procedure. This consists of preparing a detailed formal safety review report, having a committee review the report and inspect the process, developing improvements in the design and operating procedures, and implementing the recommendations. The formal

safety review report includes the following sections:

I. Introduction

- A. Overview or summary:** Provides a brief summary of the results of the formal safety review. This is done after the formal safety review is complete.
- B. Process overview or summary:** Provides a brief description of the process with an emphasis on the major hazards in the operation.
- C. Reactions and stoichiometry:** Provides the chemical reaction equations and stoichiometry.
- D. Engineering data:** Provides operating temperatures, pressures, and relevant physical property data for the materials used.

II. Raw materials and products: Refers to specific hazards and handling problems associated with the raw materials and products. Discusses procedures to minimize these hazards.

III. Equipment setup

- A. Equipment description:** Describes the configuration of the equipment. Sketches of the equipment are provided.
- B. Equipment specifications:** Identifies the equipment by manufacturer name and model number. Provides the physical data and design information associated with the equipment.

IV. Procedures

- A. Normal operating procedures:** Describes how the process is operated.
- B. Safety procedures:** Provides a description of the unique concerns associated with the equipment and materials and specific procedures used to minimize the risk. This includes:
 - 1. Emergency shutdown:** Describes the procedure used to shut down the equipment if an emergency should occur. This includes major leaks, reactor runaway, and loss of electricity, water, and air pressure.
 - 2. Fail-safe procedures:** Examines the consequences of utility failures, such as loss of steam, electricity, water, air pressure, or inert padding. Describes what to do for each case so that the system fails safely.
 - 3. Major release procedures:** Describes what to do in the event of a major spill of toxic or flammable material.
- C. Waste disposal procedure:** Describes how toxic or hazardous materials are collected, handled, and disposed.
- D. Cleanup procedures:** Describes how to clean the process after use.

V. Safety checklist: Provides the complete safety checklist for the operator to complete before operation of the process. This checklist is used before every startup.

VI. Material safety data sheets: Provided for each hazardous material used.

Example 11-4.

A toluene water wash process is shown in [Figure 11-12](#). This process is used to clean water-soluble impurities from contaminated toluene. The separation is achieved with a Podbielniak centrifuge, or Pod, because of a difference in densities. The light phase (contaminated toluene) is fed to the periphery of the centrifuge and travels to the center. The heavy phase (water) is fed to the center and travels countercurrent to the toluene to the periphery of the centrifuge. Both phases are mixed within the centrifuge and separated countercurrently. The extraction is conducted at 190°F.




Figure 11-12. Toluene water wash process before formal safety review.

The contaminated toluene is fed from a storage tank into the Pod. The heavy liquid out (contaminated water) is sent to waste treatment and the light liquid out (clean toluene) is collected in a 55-gal drum.

Perform a formal safety review of this process.

Solution

The complete safety review report is provided in [Appendix D](#). [Figure 11-13](#) shows the modified process after the formal safety review has been completed. The significant changes or additions added as a result of the review are as follows:

1. Add grounding and bonding to all collection and storage drums and process vessels
2. Add inerting and purging to all drums
3. Add elephant trunks at all drums to provide ventilation
4. Provide dip legs in all drums to prevent the free fall of solvent resulting in the generation and accumulation of static charge
5. Add a charge drum with grounding, bonding, inerting, and ventilation
6. Provide a vacuum connection to the dirty toluene storage for charging
7. Add a relief valve to the dirty toluene storage tank
8. Add heat exchangers to all outlet streams to cool the exit solvents below their flash point (this must include temperature gauges to ensure proper operation)
9. Provide a waste water collection drum to collect all waste water that might contain

substantial amounts of toluene from upset conditions




Figure 11-13. Toluene water wash process after formal safety review.

Additional changes were made in the operating and emergency procedure. They included

1. Checking the room air periodically with colorimetric tubes to determine whether any toluene vapors are present
2. Changing the emergency procedure for spills to include (a) activating the spill alarm, (b) increasing the ventilation to high speed, and (c) throwing the sewer isolation switch to prevent solvent from entering the main sewer lines

The formal safety review can be used almost immediately, is relatively easy to apply, and is known to provide good results. However, the committee participants must be experienced in identifying safety problems. For less experienced committees, a more formal HAZOP study may be more effective in identifying the hazards.

11-5. Other Methods

Other methods that are available for identifying hazards are the following:

1. “What if” analysis: This less formal method of identifying hazards applies the words “what if” to a number of areas of investigation. For instance, the question might be, What if the flow stops? The analysis team then decides what the potential consequences might be and how to solve any problems.
2. Human error analysis: This method is used to identify the parts and the procedures of a process that have a higher than normal probability of human error. Control panel layout is an excellent application for human error analysis because a control panel can be designed in such a fashion that human error is inevitable.
3. Failure mode, effects, and criticality analysis (FMECA): This method tabulates a list of equipment in the process along with all the possible failure modes for each item. The effect of a particular failure is considered with respect to the process.

Suggested Reading

Center for Chemical Process Safety (CCPS), *Guidelines for Chemical Process Quantitative Risk Analysis*, (CPQRA), 2nd ed. (New York: Center for Chemical Process Safety, AIChE, 2000).

Center for Chemical Process Safety (CCPS), *Guidelines for Developing Quantitative Safety Risk Criteria* (New York: Center for Chemical Process Safety, AIChE, 2009).

Center for Chemical Process Safety (CCPS), *Guidelines for Hazard Evaluation Procedures*, 3rd ed. (Hoboken, NJ: John Wiley & Sons, 2008).

Center for Chemical Process Safety (CCPS), *Guidelines for Risk-Based Process Safety* (New York: Center for Chemical Process Safety, AIChE, 2008).

Dow's Fire and Explosion Index Hazard Classification Guide, 7th ed. (New York: American Institute of Chemical Engineers, 1994).

Trevor A. Kletz, *HAZOP and HAZAN*, 3d ed. (Warwickshire, England: Institution of Chemical Engineers, 1992).

S. Mannan, ed., *Lees' Loss Prevention in the Process Industries*, 3rd ed. (London: Butterworth Heinemann, 2005).

Problems

11-1. The hydrolysis of acetic anhydride is being studied in a laboratory-scale continuously stirred tank reactor (CSTR). In this reaction acetic anhydride $[(\text{CH}_3\text{CO})_2\text{O}]$ reacts with water to produce acetic acid (CH_3COOH).

The concentration of acetic anhydride at any time in the CSTR is determined by titration with sodium hydroxide. Because the titration procedure requires time (relative to the hydrolysis reaction time), it is necessary to quench the hydrolysis reaction as soon as the sample is taken. The quenching is achieved by adding an excess of aniline to the sample. The quench reaction is



The quenching reaction also forms acetic acid, but in a different stoichiometric ratio from the hydrolysis reaction. Thus it is possible to determine the acetic anhydride concentration at the time the sample was taken.

The initial experimental design is shown in [Figure 11-14](#). Water and acetic anhydride are gravity-fed from reservoirs and through a set of rotameters. The water is mixed with the acetic anhydride just before it enters the reactor. Water is also circulated by a centrifugal pump from the temperature bath through coils in the reactor vessel. This maintains the reactor temperature at a fixed value. A temperature controller in the water bath maintains the temperature to within 1°F of the desired temperature.




Figure 11-14. Acetic anhydride reactor system.

Samples are withdrawn from the point shown and titrated manually in a hood.

- a. Develop a safety checklist for use before operation of this experiment.
- b. What safety equipment must be available?
- c. Perform an informal safety review of the experiment. Suggest modifications to improve the safety.

11-2. Perform a HAZOP study on the laboratory process of [Problem 11-1](#). Consider the intention “reactant flow to reactor” for your analysis. What specific recommendations can you make to improve the safety of this experiment?

11-3. A heat exchanger is used to heat flammable, volatile solvents, as shown in [Figure 11-15](#). The temperature of the outlet stream is measured by a thermocouple, and a controller valve manipulates the amount of steam to the heat exchanger to achieve the desired set point temperature.

- a. Identify the study nodes of the process.
- b. Perform a HAZOP study on the intention “hot solvent from heat exchanger.” Recommend possible modifications to improve the safety of the process.




Figure 11-15. Volatile solvent heating system.

11-4. A gas-fired furnace is shown in [Figure 11-16](#). The hot combustion gases pass through a heat exchanger to heat fresh air for space heating. The gas flow is controlled by an electric solenoid valve connected to a thermostat. The gas is ignited by a pilot light flame. A high-temperature switch shuts off all gas in the event of high temperature in the fresh air plenum.

- Determine the various ways in which this system can fail, leading to excessive heating of the plenum and possible fire.
- What type of valve (normally open or normally closed) is recommended for the gas supply?
- What is the most likely failure mode?
- A problem can also arise because of failure of the pilot light, leading to combustible gases in the furnace, heat exchanger, and chimney. Suggest at least two ways to prevent this problem.




Figure 11-16. Furnace control system.

11-5. Beverage dispensers are notorious for either taking one's money or not delivering the proper beverage. Consider a beverage dispenser that delivers a paper cup, ice, and beverage (composed of syrup and water) in a sequential order. The machine also makes change.

Identify as many failure modes as possible. Use the HAZOP guide words to identify additional possibilities.

11-6. World War II submarines used torpedo tubes with outer and inner doors. The torpedo was loaded into the tube from the torpedo room using the inner door. The inner door was then closed, the outer door opened, and the torpedo launched.

One problem was ensuring that the outer door was closed before the inner door was opened. Because no direct visible check was possible, a small pipe and valve were attached to the top of the torpedo tube in the torpedo room. Before opening the inner door, the valve was opened momentarily to check for the presence of pressurized water in the tube. The presence of pressurized water was a direct indication that the outer door was open.

Determine a failure mode for this system, leading to the inner door being opened when the outer door was open, resulting in flooding of the torpedo room and possible sinking of the sub.

11-7. Five process pumps are lined up in a row and numbered as shown in [Figure 11-17](#). Can you identify the hazard? A similar layout led to a serious accident by a maintenance worker who was sprayed by hot solvent when he disconnected a pump line on the wrong pump. An accident like this might be attributed to human error but is really a hazard resulting from poor layout.




Figure 11-17. Pump layout.

11-8. A good acronym in chemical plant design is KISS—Keep It Simple, Stupid! This also applies to hazards. Complicated designs are almost always more hazardous than simple ones.

[Figure 11-18](#) shows a sump designed to collect process fluids. The level controller and pump ensure that the sump level is maintained below a maximum height. Can you suggest a much simpler system?




Figure 11-18. Sump level control system.

11-9. Storage tanks typically are not capable of withstanding much pressure or vacuum.

Standard storage tanks are designed for a maximum of 2.5 in of water gauge vacuum (0.1 psi) and about 6 in of water gauge pressure (0.2 psi).

A welding operation was to occur on the roof of a storage vessel. The tank contained a flammable, volatile liquid. The roof was equipped with a vent pipe with a flame arrestor.

The foreman recognized a possible hazard from flammable vapor escaping from the vent pipe and igniting on the sparks from the welding operation. He connected a hose to the vent at the top of the tank and ran the hose down to the ground. Because the flammable vapors were water soluble, he stuck the end of the hose in a drum full of water. During a subsequent operation that involved emptying the tank, an accident occurred. Can you explain what happened and how?

11-10. [Figure 11-19](#) shows a storage tank blanketed with nitrogen. This configuration resulted in an explosion and fire because of loss of inert material. Can you explain why?




Figure 11-19. Nitrogen padding system for a storage tank.

11-11. [Figure 11-20](#) shows two tanks in series, both with independent level controllers.

This configuration will result in the lower tank inevitably overflowing. Can you explain why?




Figure 11-20. Level tanks in series.

11-12. Develop a safety checklist for the system described in [Example 11-3](#) and shown in [Figure 11-14](#). The intention of the checklist is to ensure the system is safe before operation.

11-13. Prepare a formal safety review memo for the gas-fired furnace described in [Problem 11-4](#) and shown in [Figure 11-16](#). This memo will be given to each committee member before the formal safety review committee meeting.

11-14. Describe an informal safety review process for using a cylinder of phosgene to charge gaseous phosgene to a reactor. Review up to the reactor only.

11-15. In [Figure 11-8](#), identify the study nodes of the reactor process, as shown.

11-16. “Fail-safe” is a concept used to specify the position of process instrumentation in the event of power, air pressure, or other utility failures. For instance, the valve supplying cooling water to a chemical reactor would fail in the open position (“fail open”) in the event of a power failure. This would provide maximum cooling to the reactor and prevent dangerous high temperatures in the vessel.

Specify the proper fail-safe positions for the valves in the following equipment. Specify either fail open or fail close.

- a.** A flammable solvent is heated by steam in a heat exchanger. The valve controls the flow of steam to the exchanger.
- b.** A valve controls the flow rate of reactant to a reactor vessel. The reaction is exothermic.
- c.** A valve controls the flow rate of reactant to a reactor vessel. The reaction is endothermic.
- d.** A valve controls the flow of natural gas to a utility furnace in a power station.
- e.** A remotely operated valve is connected to a drain on a storage tank.
- f.** A remotely operated valve is used to fill a tank from a supply line.
- g.** A valve controls combustion air to a furnace.

h. A valve controls the pressure in a steam header.

11-17. Interlocks are used to ensure that operations in a chemical plant are performed in the proper sequence. Interlocks can be mechanical or electronic. In many cases they can be as simple as a lock and key.

Specify the simplest mechanical interlock capable of achieving the following functions:

- a.** A valve cannot be closed until a furnace is shut down.
- b.** Two valves cannot both be closed at the same time.
- c.** A valve must be closed before a pump is started.
- d.** Feed to a reactor cannot be started until the reactor vessel stirring motor is activated.

11-18. A process operator is given the following instructions: "Charge 10 lb of catalyst into batch reactor A at 3 hr into the cycle." Determine at least 15 ways in which the operator might fail to perform the instructions correctly.

11-19. Thermocouples in chemical plants are usually found in sheaths. These sheaths protect the thermocouple and also allow the thermocouple to be removed and replaced without shutting down the process. One chemical plant had some thermocouples that did not have sheaths, although they looked like the sheathed type. This led to an accidental release of toxic and flammable material. Can you explain why?

11-20. Liquid levels in storage tanks are frequently determined by measuring the pressure at the bottom of the tank. In one such tank the material stored in the tank was changed and an overflow resulted. Why?

11-21. La La Pharmaceuticals has recently discovered a new drug, Lalone, in their chemical laboratories. Lalone is expected to be a blockbuster drug, raking in billions of dollars each year. For the next stage of clinical studies over 50 kg of Lalone is required, and La La Pharmaceuticals has decided to produce this in their existing pilot plant operations in Lala Land. As the safety director for the pilot plant operations, you are in charge of ensuring the safety of all operations.¹⁰

During a meeting with the chemist who synthesized Lalone in the laboratory, you have learned the following: (1) Lalone is a fine, white powder; (2) Lalone is synthesized by a batch process through a series of four major steps—three sets of reactions to produce intermediates, followed by drying to produce Lalone (all reactions are carried out in the liquid phase and require acetone as a solvent); (3) the chemical reactions are not fully understood, and most physical and chemical properties are not known; (4) so far, Lalone has been manufactured only in the laboratory and in small quantities (less than 50 g); (5) management wants the pilot plant operations to be started as soon as possible; and (6) the Engineering Division has already started writing the operating procedures for the eventual process.

As the safety director of the pilot plant:

- a. Based on your safety knowledge and experience, identify the major hazards in this process that you would be concerned about.
- b. Describe how you would structure a hazard study for the Lalone manufacturing process.
- c. What additional information will you need to conduct the hazard analysis study?

11-22. An operator was told to control the temperature of a reactor at 60°C. He set the set point of the temperature controller at 60. The scale actually indicated 0–100% of a temperature range of 0–200°C. This caused a runaway reaction that overpressured the vessel. Liquid was discharged and injured the operator. What was the set point temperature the operator actually set?

11-23. Pneumatic process equipment operates in the range of 3–15 psig. Thus, for example, a signal of 3 psig might represent 0 psig in the process and 15 psig might represent 1200 psig in the process.

A pneumatic pressure gauge was designed to operate in the range of 3–15 psig, corresponding to the pneumatic signal sent from the plant. However, the scale printed on the gauge read 0 to 1200 psig, corresponding to the actual process pressures.

This gauge was accidentally overpressured, resulting in an accident. What happened?

11-24. A light in the control room of a chemical plant indicated whether a valve was closed or not. In reality it indicated only the status of the signal being sent to the valve. The valve did not close when it should have, and the plant exploded. Why? How would you prevent this problem?

11-25. A coffee maker has a reservoir where a quantity of clean water is poured. A small heater percolates the water up to the top of the coffee maker, where it drips down through the coffee grounds and filter assembly. The coffee product is collected in the coffee pot.

- a. Draw a sketch of the coffee machine, and identify the study nodes.
- b. Perform a HAZOP study on a common coffee maker. Use as a design objective hot, fresh-brewed coffee in the coffee pot.

11-26. (This problem requires student access to the *Dow Fire and Explosion Index* manual.) In a devolatilizer, a solvent (60% cyclohexane and 40% pentane) is removed from a polymer and sent to the solvent recycle section of the plant for treatment and recovery. The devolatilizer is located in an open structure with good access for fire fighting. The process area has a 1% sloping concrete surface with a remote impounding area capable of handling all of a spill and 30 min of fire water. The process is run above the flash point of the solvent at 300 mm Hg. The vessel has a relief device set at 50 psig. Assume a potential spill of 8000 lb of flammable material with a heat of combustion of 19.4×10^3 Btu/lb.

The process unit has many loss control features. The plant has a diesel emergency power generator with an emergency cooling system. The plant is also under

computer control with emergency shutdown based on redundant inputs. Vacuum is always broken with nitrogen. The process has complete, written, and up-to-date operating instructions. A reactive chemicals review was completed recently. The process has several interlocks to prevent polymerization.

The process area has combustible gas detectors, fireproofing, and a water deluge system. Cable trays are protected with deluge, and portable dry chemical extinguishers are in the process area. Diesel-powered fire water pumps can provide a maximum fire water demand for 4 hr.

- a.** Determine the Dow F&EI value for this process to estimate the relative degree of hazard.
- b.** Assuming an equipment value within the radius of exposure of \$1 million, estimate the maximum probable property damage.
- c.** Assuming a product value of \$1.50 per pound and an annual plant production rate of 35 million lb, estimate the business interruption loss.

11-27. (This problem requires student access to the *Dow Fire and Explosion Index* manual.) Consider a butadiene storage vessel in a tank farm area containing butadiene, cyclohexane, isopentane, styrene, and isopropene. The maximum butadiene storage capacity is 100,000 gal. The normal pressure of the butadiene storage vessel is 15 psig, with the relief valve set at 50 psig. The butadiene storage is diked separately from the other materials. The butadiene storage area is equipped with a chilled glycol cooling system that can be operated from an emergency generator if necessary. The transfer operations in and out of storage are monitored by computer control with emergency shutdown capability. The vapor space in the vessel is inerted. Operating instructions are current, and the system has been through a recent reactive chemicals review.

The storage system has remotely operated emergency block valves on all transfer lines into and out of the tank. The storage area has the required drainage to direct a spill away from the tank. Backflow protection has been installed and is tested to prevent backflow into the transfer line and storage.

Loss control features include combustible gas detectors installed around the containment area and transfer system. A diesel-driven fire pump is capable of handling the emergency demand for 4 hr. A water deluge system has been installed around the storage tank and transfer pump.

The specific gravity of the butadiene is 0.6263.

- a.** Determine the Dow F&EI value for this process to estimate the relative degree of hazard.
- b.** Assuming an equipment value within the radius of exposure of \$1 million, estimate the maximum probable property damage.
- c.** Assuming a product value of \$2.00 per pound for this plant and an annual production rate of 10 million lb, estimate the business interruption loss.

11-28. Exothermic chemical reactions are frequently dangerous because of the potential

for a runaway reaction. Cooling coils are provided in batch reactors to remove the energy of reaction. In the event of a cooling water failure, the reactor temperature rises, resulting in a higher reaction rate and higher energy generation. The result is a runaway reaction. During a runaway reaction, the temperature can rise quickly, resulting in dangerous pressures within the reactor and a possible explosion.

Loss of cooling can be detected by measuring the temperature within the reactor and sounding an alarm. Frequently, by the time the alarm sounds, it is too late. Design a better instrumentation and alarm configuration to detect loss of cooling more directly. Draw the instrumentation diagram.

11-29. A flammable liquid is to be stored in a large storage vessel. Two vessels are available. One vessel is called a weak seam roof tank, with the weakest part of the vessel being the welded seam between the roof and the vertical wall of the tank. The other vessel is a domed roof tank, with the weakest part being the seam along the bottom of the tank. Which tank is the better choice for storing this material?

11-30. Your manufacturing plant has purchased a number of robots to facilitate production. What are the main hazards associated with robots? What are some effective safeguards against these hazards?¹¹

11-31. As described in [Section 11-4](#), checklists are used to facilitate a high-quality safety review, and the checklists are tailored for a specific process and a specific group of reviewers (for example, experienced or inexperienced reviewers). Tailor a checklist for a group of chemical engineering students who are preparing to review a new ChemE Car for the annual AIChE ChemE Car competition.

11-32. Safety reviews should include a review and study of previous incidents and accidents, as described in [Section 11-4](#). Part of the solution to [Problem 11-31](#) includes a review of previous accidents. Summarize the accidents that have previously occurred in AIChE ChemE Car competitions, and state the teaching relevant to new competitors. (See ChemE Car Safety, Workshop Presentation (PDF), www.SACHE.org.)