BIRLA INSTITUTE OF TECHNOLOGY, MESRA, RANCHI (MID SEMESTER EXAMINATION SP/2024)

CLASS: B TECH SEMESTER : IV/ADD BRANCH: MECHANICAL/PIE SESSION : SP/2024

SUBJECT: ME207 KINEMATICS & DYNAMICS OF MACHINES

TIME: 02 Hours FULL MARKS: 25

INSTRUCTIONS:

1. The question paper contains 5 questions each of 5 marks and total 25 marks.

2. Attempt all questions.

3. The missing data, if any, may be assumed suitably.


4. Tables/Data handbook/Graph paper etc., if applicable, will be supplied to the candidates

.....


- Q.1(a) Which inversion is obtained by fixing the slider in a slider-crank mechanism? Draw [2] 1 Understand a schematic diagram.

 Q.1(b) Calculate the number of degrees of freedom for the linkage shown in Figure. [3] 1 Apply

 - Q.2 In a slider-crank mechanism, the lengths of the crank and the connecting rod are [5] 1 Analyze 200 mm and 800 mm respectively. Find the velocity of the slider and the angular velocity of the connecting rod at the instant when the crank has turned 30° from the inner dead centre, rotating anticlockwise at 40 rad/s.



- Q.3 Derive an expression for the acceleration of slider in a slider-crank mechanism. [5] 2 Apply
- Q.4 The dimensions of a four-link mechanism are AB = 500 mm, BC = 660 mm, CD = [5] 2 Evaluate 560 mm and AD = 1000 mm. The link AB has an angular velocity of 10.5 rad/s counter-clockwise and an angular retardation of 26 rad/s² at the instant when it makes an angle of 60° with AD, the fixed link. The mass of the links BC and CD is 4.2 kg/m length. The link AB has a mass of 3.54 kg, the centre of which lies at 200 mm from A and a moment of inertia of 88500 kg.mm². Find the inertia forces and inertia couples acting on each link. The acceleration diagram is shown in Figure.



Q.5 A circular disc mounted on a shaft carries three attached masses of 4 kg, 3 kg and 2.5 kg at radial distances of 75 mm, 85 mm and 50 mm and at the angular positions of 45°, 135° and 240° respectively The angular positions are measured counter-clockwise from the reference line along the x-axis. Determine the amount of the countermass at a radial distance of 75 mm required for the static balance.

:::::20/02/2024:::::M

Evaluate